

ハイブリッド記録計 [形式:SR107シリーズ] 取扱説明書の補足説明

このたびはハイブリッド記録計SR107シリーズをお買い上げいただき、ありがとうございます。
本製品に添付されている取扱説明書に補足がございますので、お手数ですが、以下の内容を併せてお読みいただきますようお願い申し上げます。

<補足説明1>

取扱説明書 P 4-1 「4.2 電源配線の注意事項」に以下の④～⑦の説明が追加されます。

- ④電源スイッチ(又はブレーカー)は電源設備内に備えてください。
- ⑤電源スイッチ(又はブレーカー)は容易に手が届く範囲に適切に付けてください。
- ⑥電源スイッチ(又はブレーカー)には、本製品の遮断装置であることを表す表記をおこなってください。
- ⑦電源配線は、接地する国の規格に従って配線作業者が配線してください。

<補足説明2>

取扱説明書 P 12-6 「正常動作条件」に以下の説明が追加されます。

- ・使用環境 : 屋内
- ・高 度 : 2000m以下

Supplementary explanations for the Instruction Manual Hybrid Recorder [Type: SR107 Series]

Thank you for your purchase of a Hybrid Recorder SR107 Series .
The following explanations are added to the instruction manual. Please read them through and follow the instructions.

<Supplementary explanation 1>

P4-1:Explanations 4) to 7) are added to the section "4.2 Caution on power source wiring".

- 4) A switch (or a circuit-breaker) must be included in the installation.
- 5) A switch (or a circuit-breaker) must be suitably located and easily reached.
- 6) A switch (or a circuit-breaker) must be marked as the disconnecting device for this equipment.
- 7) Supply wiring shall be prepared by installers in accordance with national regulations

<Supplementary explanation 2>

P12-6:Explanation is added to the section "Normal operating condition".

- Usage environment : Indoor
- Operating altitude : 2000m max.